

August[®]

User Manual

Wireless Presentation Laser Pointer with Timer
Présentateur pointeur Laser avec changeur de page et minuterie
Schnurloser Presenter mit Laserpointer und Timer
Puntatore Laser senza fili per presentazioni, con timer
Puntero Láser Inalámbrica con Temporizador

LP107T



August International Ltd
United Kingdom
Telephone: +44 (0) 845 250 0586
Email: service@augustint.com
Web: www.augustint.com

1. Introduction

The wireless presenter is suitable for any presentation or PowerPoint occasion. With it, you don't need to stand beside your computer or have an assistant. It is very simple to use, just plug and play, and no driver is required.

The device enables you to control your presentation wirelessly up to 10 metres (32 feet) away, thanks to the advanced radio frequency (RF) technology that works through walls.

It combines the functions of a laser pointer, remote control and timer. It is tailored as a convenient tool for presentations, teaching, meetings, speeches and training.

2. Operating system

The device supports Windows 98 / ME / 2000 / 2003 / XP / Vista / 7 / 8, Linux and Mac OS.

3. Parts & Functions

3.1 Front



Note:
Press F5/Esc to start or exit a Powerpoint slideshow.

3.2 Back

Pull out the USB receiver



4. Battery Installation

- The unit is powered by 2 x AAA batteries
- Remove the battery compartment cover
- Insert 2 x AAA batteries into the battery holder
- Put the battery compartment cover back in position



Note:

- 1) Do not insert batteries into the presenter in the wrong direction.
- 2) Do not leave bad or exhausted batteries in the presenter.
- 3) If you do not use the presenter for a long period of time, remove the batteries to avoid possible damage from battery corrosion.
- 4) If the presenter does not function correctly or if the operating range becomes reduced, try to replace the batteries with new ones.

5. Setup

Plug the USB receiver into the USB port on your computer. The system will automatically search for the new hardware and complete the installation.

6. Timer setting

- 1) Press Timer on the side of the device, [000] appears and starts flashing. Press Timer repeatedly to select the length of your presentation.

Note:

The time increases by 5 minutes from 0 to 60 minutes and by 10 minutes from 60 to 590 minutes.

- 2) Stop pressing Timer when it reaches the time desired. The digits will stop flashing to confirm your choice.
- 3) When there are 5 minutes remaining, it will remind the user by vibrating every time the time decreases by one minute.
- 4) If you wish to cancel the timer setting, press and hold Timer until the LCD displays [000].

Note:

[000] on the LCD screen corresponds to 0 minute. For example, the timer is set to 120 minutes when it shows [120] on the screen.

7. Technical parameters

Presenter	
Control Distance	10 meters
Technology	Radio Frequency
Frequency range	2400 ~ 2483MHz
Operating voltage	1.8 – 3.3V
Laser Output power	<1mW
Laser wavelength	640nm
Power supply	2 x AAA batteries
Size	120x40x20mm
Weight	56g (inc. batteries)
USB Receiver	
Operating System	Windows 98/ME/2000/XP/Vista/7/8, Mac OS, Linux
Working Voltage	4.5 – 5.5V
USB Version	USB1.1 compatible with 2.0, 3.0
Size	56x18x9mm
Weight	6g

Warning:

Laser radiation

Class 2 laser product

Do not view directly with optical instruments

Do not point at people and animals

Please keep out of reach of children

Note:

Please note this instruction is only intended for reference. August International Ltd reserves rights to revise the product specifications, features and design without notice.